


ASSEMBLY INSTRUCTIONS

Iconic Arc Lamp with Morelli Shade



IMPORTANT SAFETY INSTRUCTIONS

This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.


INSTRUCCIONES DE SEGURIDAD IMPORTANTES




Esta lámpara tiene un enchufe polarizado (una de las clavijas es más ancha que la otra) como medida de seguridad para reducir el riesgo de descarga eléctrica. Este enchufe solo encaja en una toma de corriente polarizada de una sola manera. Si el enchufe no entra completamente en la toma, gírelo. Si aun así no encaja, contacte con un electricista cualificado. No lo utilice nunca con un cable de extensión a menos que el enchufe pueda insertarse completamente. No modifique el enchufe.

ASSEMBLY INSTRUCTIONS

Iconic Arc Lamp with Morelli Shade

- Carefully remove all parts from the carton and place them on a clean surface. Please refer to the list of included items inside the carton.
- Insert the base hardware tapered nut (C1) through the opening in the side of the base (B) into the center hole.
- Position the column (A3) into the slot at the back of the base (B). While holding the base hardware tapered nut (C1) in place, insert the base hardware bolt (C2) through the back of the lamp body column (A3) and secure it in place.
- Remove the four bolts from lamp body arms (A1, A2)
- Insert the front arm section (A1) into the back arm section (A2). Position the arm at the optimal height for your environment and secure with two of the bolts. Cable may need to be pulled at the bottom of the lower arm section (A2) to remove slack between sections.
- Repeat previous step for attaching the arm sections (A1, A2) into the column (A3). Pulling cable slack from the bottom of the column (A3).
- Insert the pressure fit base caps (D) into the openings on either side of the base, making sure the text is level.
- Attach shade (E) and harp (F1) to socket of the lamp body (A) and secure with socket ring (H).
- Insert the light bulb (I) into the socket.
- Attach diffuser (G) to the bottom of the harp (F1) and secure with the finial (F2).
- Connect plug into dimmer switch (J).
- Plug into a surge protected 120v outlet and enjoy the beautiful light!



ITEMS INCLUDED / ARTÍCULOS INCLUIDOS									
A (1-3)  COLUMN & ARM SECTIONS/ SECCIONES DE COLUMNA Y BRAZO	B  BASE/ BASE	C (1-2)  BASE HARDWARE/ HARDWARE BASE	D   X2 BASE CAP/ GORRA DE BÉISBOL	E  SHADE/ PANTALLA	F (1-2)  HARP & FINIAL/ ARPA Y REMATE	G  DIFFUSER/ DIFUSORA	H  SOCKET RING/ ANILLO DE ENCHUFE	I  BULB/ BOMBILLA	J  DIMMER SWITCH/ INTERRUPTOR DE ATENUACIÓN

IMPORTANT SAFETY INSTRUCTIONS

This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

INSTRUCCIONES DE SEGURIDAD IMPORTANTES

Esta lámpara tiene un enchufe polarizado (una de las clavijas es más ancha que la otra) como medida de seguridad para reducir el riesgo de descarga eléctrica. Este enchufe solo encaja en una toma de corriente polarizada de una sola manera. Si el enchufe no entra completamente en la toma, gírelo. Si aun así no encaja, contacte con un electricista cualificado. No lo utilice nunca con un cable de extensión a menos que el enchufe pueda insertarse completamente. No modifique el enchufe.