

ASSEMBLY INSTRUCTIONS

2711178PC Tripod Floor Lamp



- 1.) Carefully remove lamp from box. Stand lamp base (A) on a flat surface.
- 2.) Adjust the (X3) legs to balance the lamp.
- 3.) To operate the lamp, press and hold the dimmer switch (B). The longer the switch is pressed, the brighter the light. Continue to press until the desired brightness is achieved
- 4.) To turn off the lamp, re-press and hold the dimmer switch (B); the lamp will start to dim. Continue to press until the light is completely turned off.

INSTRUCCIONES DE ENSAMBLE

2711178PC Lámpara de Pie para Trípode

- 1.) Quite cuidadosamente la lámpara de la caja. Coloque la base de la lámpara (A) sobre una superficie plana
- 2.) Ajuste las (X3) patas para equilibrar la lámpara.
- 3.) Para operar la lámpara, mantenga presionado el interruptor del atenuador (B). Cuanto más tiempo presione el interruptor, más brillante será la luz. Continuar presionando hasta alcanzar el brillo deseado
- 4.) Para apagar la lámpara, vuelva a presionar y mantenga presionado el interruptor del atenuador (B); la lámpara comenzará a oscurecerse. Continúe presionando hasta que la luz se apague completamente.

#2711178PC, white background with black words, pre-attached on the bottom of base

Style and producing date:

ITEM NO.:2711178PC
DATE: . APR. 2017
MADE IN CHINA

LED label:

CAUTION:
USE 18W WARM WHITE
3000K LED 12V/1.5A

Diver Spec:

ITEM NO.:2711178 PC
LED POWER:DC 12V/2.5A
BATCH CODE: .04/2017

