



ASSEMBLY INSTRUCTIONS

LODI 1-LIGHT ARC FLOOR LAMP

2110500MB

1. Carefully remove all parts from the box and place them on a clean surface below. Please refer to the list below of items included inside the carton.
2. Insert threaded arm tube (A) into tapped arm tube (B) and secure it in place by rotating until snug.
3. Align and snap together the male-female connector (D) located at the top of the column (F) with the male-female connector at the bottom of the arm assembly (B).
4. Insert the solid wood disk (G) onto the threaded tube under the column (F).
5. Attach the washer (I) and nut (J) on to the threaded tube under the column (F), using 17mm wrench (K) provided. You will find the required hardware attached onto the bottom of the threaded tube (F).
6. Insert the arm assembly housing (A+B) into the column (F) and secure it using thumbscrew (E). You will find this attached to the top of column (F).
7. Insert the bulb (L) into the socket.
Bulb: A19 120V 14W 2700K E26 Flicker-free Dimmable LED (included).
8. Plug into a 110V outlet.
9. Enjoy the beautiful light!



ITEMS INCLUDED / ARTICULOS INCLUIDOS						
F  TUBE TUBO	G  DISK DISCO	I  WASHER ROSCA	K  WRENCH TUERCA	A+B  ARM ASSEMBLY BRAZO	E  THUMB SCREW TORNILLO	L  BULB BOMBILLA
	H  BASE BASE	J  NUT TUERCA				

For a step by step assembly video,
please go to
www.novaofcalifornia.com

IMPORTANT SAFETY INSTRUCTIONS

This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

IMPORTANTES INSTRUCCIONES DE SEGURIDAD

Esta lampara tiene un enchufe polarizado (una navaja es mas ancha que la otra) como forma de seguridad para reducir el riesgo de un shock electrico. Este enchufe polarizado entrara en una conexi3n solo de un lado. Si el enchufe no entra en la conexi3n trate al reverso. Si aun asi no entra, contacte a un electricista calificado. Nunca use una extension a menos que el enchufe pueda ser conectado completamente. No altere el enchufe.