



ASSEMBLY INSTRUCTIONS

Morelli Wall Arc

1. Carefully remove all parts from the carton and place them on a clean surface. Please refer to the list of included items inside the carton.
2. Place the mounting plate (A) against the wall in the desired mounting location, ensuring the two threaded studs are level. Use a pencil to mark the wall at (4) evenly distributed points in the holes or slots of the mounting plate (A). Set aside the mounting plate (A).
3. Drill holes (4) for the provided anchors, then insert them into the holes. Place the mounting plate (A) on the wall and secure it in place with the screws provided.
4. Align the lamp body (B) onto the mounting plate (A) studs and use the thumb screws (C) to secure it in place.
5. Attach shade (D) and harp (E1) to socket of the lamp body (B) and secure with socket ring (F).
6. Insert the light bulb (G) into the socket.
7. Attach diffuser (H) to the bottom of the harp (E1) and secure with the finial (E2).
8. Plug into a surge protected 120v outlet and enjoy the beautiful light!



ITEMS INCLUDED / ARTÍCULOS INCLUIDOS

A	B	C	D	E (1-2)	F	G	H
MOUNTING PLATE/ PLACA DE MONTAJE	LAMP BODY/ CUERPO DE LA LÁMPARA	THUMB SCREWS/ TORNILLOS DE MARIPOSA	SHADE/ PANTALLA	HARP & FINIAL/ ARPA Y REMATE	SOCKET RING/ ANILLO DE ENCHUFE	LIGHT BULB/ BOMBILLA	DIFFUSER/ DIFUSORA

IMPORTANT SAFETY INSTRUCTIONS

This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

INSTRUCCIONES DE SEGURIDAD IMPORTANTES

Esta lámpara tiene un enchufe polarizado (una de las clavijas es más ancha que la otra) como medida de seguridad para reducir el riesgo de descarga eléctrica. Este enchufe solo encaja en una toma de corriente polarizada de una sola manera. Si el enchufe no entra completamente en la toma, gírelo. Si aun así no encaja, contacte con un electricista cualificado. No lo utilice nunca con un cable de extensión a menos que el enchufe pueda insertarse completamente. No modifique el enchufe.